

Camping Lamp



USER MANUAL


Please read this manual carefully before use to ensure that the product can be used correctly

Instructions

- Operating instructions: briefly press the knob switch to turn on the warm light mode, briefly press the switch again to switch to the white light mode, briefly press the switch again to switch to the mixed light mode, briefly press the switch again to switch to the red sos light mode, and briefly press the switch again to turn off the light; Double click the knob switch to turn on the flashlight. Double click the knob switch again to turn off the flashlight.
- Rotate the switch to adjust the light brightness; In any mode, long press the knob switch to turn off all lights.

Indicator Status	Electricity Status
● ● ● ● Four lights on	75%–100%
● ● ● ○ Three lights on	50%–75%
● ● ○ ○ Two lights on	25%–50%
● ○ ○ ○ One light on	≤25%

Product Diagram



Product Specification

Model: DQ311	Color temperature: 1800–7000K
Input Output: DC5.0V/2A	Battery Capacity: 10000mAh
Rated Power: ≤10W	Size: 65x65x182mm
Weight: 388g	Raw Material: ABS/PP/PCBA
Lumen: 30–720LM	Standard: GB7000.1–2015
Made in China	GB7000.204–2008

Product Contents

Camping lampX1、Hand strapX1、USB cableX1、ManualX1

Note

- The best use and storage environment temperature of the product is -10°C to 45°C . Do not use the product in extremely cold and hot environments.
- It is forbidden to direct the light to the eyes. Children should use the product correctly under the supervision and guidance of adults.
- Do not disassemble or repair this product without permission to avoid accidents or possible damage to the product.
- Please use high-quality power socket and standard USB charging cable to charge this product.